

MODEL NO. T1640-98

SERIAL NO. 233508465



SUBSIDIARY OF TRIUMPH-ADLER

BLANK

MODEL NO. T1640-98

SERIAL NO. 233508465



9600 IRONDALE AVE., CHATSWORTH, CALIF. 91311  
PHONE (213) 882-0030 TWX (910) 494-2093

### **WARNING**

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions manual, may cause interference to radio communications. As temporarily permitted by regulation, it has not been tested for compliance with the limits for Class A computing devices pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference. Operation of this equipment in a residential area is likely to cause interference, in which case the user at his own expense will be required to take whatever measures may be required to correct the interference.

PART NO.	REFERENCE DESIGNATION
107-1015	R24, 69, 171, 132, 137, 127, 154, 158, 176
107-1025	R1, 3, 14, 18, 21, 22, 42, 44, 54, 62, 62, 73, 73, 79, 84, 85, 87, 97, 98, 107, 129, 93, 111, 132, 123, 144, 181, 185, 150, 151, 152, 155, 164, 167, 171, 172, 173
107-1035	R2, 4, 6, 8, 10, 11, 13, 16, 17, 27, 45, 52, 55, 85, 57, 61, 63, 67, 71, 115, 121, 130, 149, 165, 167, 169
100-1045	R38, 50, 75
100-1055	R5, 15, 53, 86, 131, 134, 173
100-1065	R174, A95
100-1835	R34, 35, 76, 114, 122, 166
100-2225	R156, 99
100-3315	R108, 125, 126
100-4705	R91
100-4715	R128, 139
100-4725	R7, 9, 12, 19, 74, 129, 136, 138, 178, 180
100-5605	R 96, 104, 116, 117, 118, 119, 120, 124, 113
100-2725	R46, 110
100-5535	R158
101-2215	R88
111-107	R175
101-1015	R146, 153, 157
403-1805	R30, 47
102-1515	R177
103-1015	R51
103-4715	R135, 148
107-1001	R27, 106
107-1002	R25, 37, 39, 40, 41, 49, 103
107-1003	R48
107-2151	R94
107-3832	R36
107-6810	R 64
107-6811	R26
107-5112	R72
108-4715	R23, 68
109-0500	R133
109-2715	R43
111-0001	R89
115-0003	R31, 32, 33, 81, 82, 83
118-0013	6127
121-5010	R59
121-1020	R47, 175
130-1015	C29, 14
130-2215	C18
130-3315	C4
131-6820	C39
131-3320	C2, 5, 8, 34
131-4720	C3, 6, 7
131-6890	C33


PART NO.	REFERENCE DESIGNATION
135-17B1	C12, 13, 32, 40
139-1260	C21
139-2244	C 19, 25, 30, 31
139-2262	C9, 10, 17, 20, 16
139-3392	C15
139-6845	C 24, 28, 35, 36
142-1070	C26, C22, 38
142-5960	C1, 11
200-0013	Q 20
200-0041	Q19, 42, 43, 45, 47,
200-0042	Q6, 36
200-0004	Q 32, 35
200-4037	Q41,
200-4023	Q2, 4, 11, 17, 18, 24, 30, 31, 37, 51, 52, 55, 56, 5
200-4125	Q1, 3, 13, 14, 28, 29, 33, 34, 50, 54, 38, 58
200-4848	Q7, 8, 9, 21, 22, 23
200-5321	Q10
200-5523	Q16, 27, 44, 46
200-3772	Q 26
201-0126	SCR2, 3
201-3669	SCR1
204-0074	Q5, 12, 15, 25, 53
300-4002	CR1, 4, 5, 8, 10, 11
300-4446	CR2, 3, 6, 7, 9, 12
330-0475	VR4, 5, 9
330-0565	VR1
330-0515	VR7
331-1225	VR8
331-1905	VR3, 6
331-0335	VR2
400-0805	U2
400-0807	U3, 8, 9, 10, 15
400-0825	U1
400-0818	U12
408-0922	U4, 13
710-7400	U5, 11, 14
710-7404	U7
710-7410	U6

TABLE II																			
ASSEMBLY 19458 VERSION NO.	VERSION CHARACTERISTIC	Q39, 40, 48, 49 R140, 141, 142, 143, 159, 162 161 162 USAGE	R112		R28, 29		R58, 65, 77		C 37	LI	R90		R92		R105		W I	R 66, 78	
			VALUE	PART NO.	VALUE	PART NO.	VALUE	PART NO.			131-2060	515-1011	VALUE	PART NO.	VALUE	PART NO.		VALUE	PART NO.
-01	BASIC	OMIT	0.3	118-0783	26.1K	107-2612	82.5	107-0825	OMIT	OMIT	C.1	110-0011	10	100-1005	39	101-3905	OMIT	500	121-5000
-02	GCR	OMIT	0.15	118-0013	16.2K	107-1622	562	107-5620	USE	USE	C.1	110-0011	10	100-1005	39	101-3905	OMIT	1000	121-1020
-03	OEM STD	OMIT	0.3	118-0033	26.1K	107-2612	82.5	107-0825	OMIT	OMIT	0.03	110-0003	—	OMIT	—	OMIT	100-0005	500	121-5000

PART NO.	REFERENCE DESIGNATIONS
100-1015	R143, 162
100-1025	R140, 142, 159, 160
101-1015	R141, 161
200-0041	Q40, 49
200-4037	Q39
200-5323	Q48

GROUND & VOLTAGE PIN NO.				
I.C. TYPE	+15V	+5V	GND (R)	-15V
74LS00		14	7	
74LS04		14	7	
74LS10		14	7	
LM307	7			4
LM318	7			4


LAST USED	NOT USED	DELETED
C 40		C27,C23
CR12		
P11	P1-10	
Q58		
L1		
R181		R107
SCR3		
1P72	R6	
U15		
VR9		
W1		





- TP3, 4, 5 THRU 17, 14, 16, 17, 20, 21, 22, 23, 25 THRU 48, 53, 54, 60 THRU 64, 66, 67, 68, 69, 72
  - COMPONENTS REQUIRE HEATSINK.
  - RESISTORS WITH 1% TOL. ARE 1/8W.
  - SIGNALS ARE CROSS-REF BETWEEN SHEETS AND WITHIN A SHEET BY NUMBERS APPEARING UNDER THE ASSOCIATED LOGIC TERM MNEMONIC. THE FIRST NO. IS THE SHEET NO. AND THE SECOND NO. IS THE ZONE NO.
  - DIODES ARE 1N4466.
  - PNP TRANSISTORS ARE 2N4125.
  - NPN TRANSISTORS ARE 2N4123.
  - CAPACITOR VALUES ARE IN MICROFARADS, 20%, 35V.
  - RESISTOR VALUES ARE IN OHMS, 5%, 1/4W.
  - FOR SPARE LOGIC ELEMENTS, SEE TABLE V.
  - FOR I. C. GENERIC TYPE NO. AND GROUND/VOLTAGE PIN NOS. SEE TABLE IX.
  - FOR PART NUMBER, SEE TABLE III.
  - FOR VALUE, PART NUMBER AND USAGE OF COMPONENTS AFFECTED BY VERSION NUMBER, SEE TABLE II.
  - FOR PART NUMBER OF COMPONENTS NOT AFFECTED BY VERSION NUMBER, SEE TABLE I.
- NOTES: UNLESS OTHERWISE SPECIFIED

THIS DRAWING IS UNDER CONFIGURATION CONTROL.

The information furnished is the property of the U.S. Government and is loaned to you and is to be controlled, stored, handled, and disposed of in accordance with the instructions of the agency to which it was loaned. It is not to be distributed outside that agency.	SIGNATURES _____ DR. 1 (10/27/71) 2/4 CHA. BLAN 2/4 DR. 2 PERSON 4/4 INC. INGA	DATE _____ 10/27/71	<b>PERTEC</b> PERIPHERAL EQUIPMENT DIVISION  <b>SCHEMATIC</b> <b>CAPSTAN/REGULATOR</b>	TITLE _____  104757 NO NET SCALE ENG. 1 SHEET OF 3 MAN. RED	NET 15
	ONSCREENING JUNE 8 BOXES TOLERANCE: _____ JOB IS _____ 5 BOX _____ ANCHOR 5 LIFT BREAK ALL SHARP CORNERS APPROX. #18	MATL _____  FINISH: _____			
















REVISIONS					
REV	DESCRIPTION	DATE	DR	CHK	APPR
A	ERN8-YC PRE PROD RELEASE	7/26/77	MM	MM	MM
B	ECN 9653A	7/27/77	MM	MM	MM
C	ECN 9-NT PROD RELEASE	7/27/77	MM	MM	MM
D	ECN 10065	8/1/77	MM	MM	MM
E	ECN 10465B	8/1/77	MM	MM	MM
F	ECN 11127	8/1/77	MM	MM	MM
G	ECN 11204	8/1/77	MM	MM	MM
H	ECN 11736	8/1/77	MM	MM	MM
I	ECN C12074	8/1/77	MM	MM	MM
J	ECN C12190	8/1/77	MM	MM	MM
K	ECN C13495B	8/1/77	MM	MM	MM
L	ECN C15079	8/1/77	MM	MM	MM
M	ECN C17173	8/1/77	MM	MM	MM
N	ECN C17567	8/1/77	MM	MM	MM
O	ECN C17826	8/1/77	MM	MM	MM
P	ECN 18073	8/1/77	MM	MM	MM
R	ECN C18411	8/1/77	MM	MM	MM

SPECIFICATION: 104809  
SCHEMATIC: 104805  
REF DWGS:

THIS DRAWING IS UNDER CONFIGURATION CONTROL.  
PART NO. 104806-03 REV AA

QTY.	PART NO.	DESCRIPTION	MATERIAL	FIN.	REF. DES.	ITEM NO.
LIST OF MATERIAL						
SIGNATURES						
DATE						
PERTEC PERIPHERAL EQUIPMENT						
TITLE						
PCBA						
DATA L						
SIZE CODE IDENT NO. DWG NO.						
E 104806						
SCALE 2:1 FINISHED DO NOT SCALE DWG. SHEET						

4. DELETED.

3 MARK VERSION NO. AND VERSION ISSUE LETTER IN AREA SHOWN.

2 THIS ASSEMBLY SHALL BE MADE FROM PROCESS BOARD 104807-01 REV B AND SUBSEQUENT.

1. ASSEMBLE PER STANDARD MANUFACTURING METHODS.

NOTES: UNLESS OTHERWISE SPECIFIED

BLANK

REVISIONS				
REV	DESCRIPTION	DATE	OR	CHK
A	ECN 8-10 PRE-PRODUCTION REL	8/28/79	J	W
A1	ECN 9-13	9/13/79	J	W
B	ECN 9-10 PROD. RELEASE	9/10/79	J	W
D	ECN 10-14	10/14/79	J	W
C	ECN 10-215	10/21/79	J	W
D	ECN 10-217	10/21/79	J	W
E	ECN 10-264	10/26/79	J	W
F	ECN 11-379	11/37/79	J	W
G	ECN 11-486	11/48/79	J	W
H	ECN 11-641	11/64/79	J	W
I	ECN C12190	12/19/79	J	W
J	ECN C13088	1/30/80	J	W
K	ECN C13941A	1/39/80	J	W

TABLE I (1)

PART NO.	REFERENCE DESIGNATION
100-1025	R2, 4, 5, 11, 18, 22, 23, 27, 29, 30, 31, 33 THRU 38, 412, 414, 511, 512, 514, 611, 612, 614, 711, 712, 714, 811, 812, 814, 911, 912, 914, 2, 4, 25
100-1035	R13,
100-1045	R9
100-1225	R15,
100-1515	R26, 32
100-1525	R102, 202, 302, 402, 502, 602, 702, 802, 902
100-1535	R8
100-1815	R104, 116, 204, 216, 304, 316, 404, 416, 504, 516, 604, 616, 704, 716, 804, 816, 904, 916
100-1825	R20
100-2225	R7, 12
100-2245	R10
100-2735	R103, 203, 303, 403, 503, 603, 703, 803, 903
100-3315	R19
100-3325	R108, 208, 308, 408, 508, 608, 708, 808, 908
100-3935	R3
100-4725	R6, 28
101-1015	R17, 107, 109, 207, 209, 307, 309, 407, 409, 507, 509, 607, 609, 707, 709, 807, 809, 907, 909
101-1025	R1, 21
101-1215	R39, 40, 41, 42
101-6205	R16
101-7505	R105, 205, 305, 405, 505, 605, 705, 805, 905
107-1212	R110, 210, 310, 410, 510, 610, 710, 810, 910
107-1621	R106, 206, 306, 406, 506, 606, 706, 806, 906
107-3161	R113, 213, 313, 413, 513, 613, 713, 813, 913
107-8251	R115, 215, 315, 415, 515, 715, 815, 915
120-0001	U22, 25
121-1030	R101, 201, 301, 401, 501, 601, 701, 801, 901
130-4705	C3, 20
135-4742	C5
139-2244	C1, 2, 4, 7 THRU 19, 21, 22
200-4037	C101, 201, 301, 401, 501, 601, 701, 801, 901, 102, 202, 302, 402, 502, 602, 702, 802, 902, 103, 203, 303, 403, 503, 603, 703, 803, 903
200-4123	C2, 104, 105, 204, 205, 304, 305, 404, 405, 504, 505, 604, 605, 704, 705, 804, 805, 904, 905
200-4125	Q1

TABLE I (1) (CONT'D)

PART NO.	REFERENCE DESIGNATION
200-5523	Q3, 4
300-4446	CR1
400-2741	U38
700-7416	U33, 37
710-4132	U21, 24, 28
700-4221	U2, 5, 7, 10, 12, 15, 17, 20, 23, 35
710-7400	U31, 32
710-7404	U34
710-7414	U27
710-7438	U36
710-7474	U4, 9, 14, 19, 26
710-7476	U1, 6, 11, 16, 30
710-7486	U3, 8, 13, 18, 29

TABLE II (2)

ASSEMBLY 104811 VERSION NO.	VERSION CHARACTERISTIC	C6		C101, 201, 301, 401, C501, 601, 701, 801, C901		C102, 202, 302, 402, C502, 602, 702, 802, C902	
		VALUE	PART NO.	VALUE	PART NO.	VALUE	PART NO.
-01	75 IPS	.0022	131-2220	750 PF	130-7515	56 PF	130-5605
-02	100 IPS	.0022	131-2220	750 PF	130-7515	43 PF	130-4305
-03	112.5/125 IPS	.0015	131-1520	560 PF	130-5615	33 PF	130-3305

TABLE V (5)





TABLE IV (4)

I.C. TYPE	+5V (L) PIN NO.	GND PIN NO.
7416	14	7
74LS00	14	7
74LS04	14	7
74LS38	14	7
74LS74	14	7
74LS76	5	13
74LS96	14	7
74LS21	16	8
74LS14	14	7
74LS132	14	7

REFERENCE DESIGNATION

LAST USED		NOT USED		DELETED	
	(1)		(2)		(3)
C22	C2	—	—	—	—
CR1	—	—	—	—	—
Q4	Q5	—	—	—	—
R42	R16	—	—	R14	—
TP48	—	TP3 THRU 24, 43, 44, 46	—	—	—
U38	—	—	—	—	—





- (1) RESISTOR NETWORK U22 & U25 ARE SPECIFIED AT TOP ASSY.  
 13. ALL UNMARKED GND'S ARE 0V (I).  
 (2) PARTIAL REFERENCE DESIGNATIONS ARE SHOWN. FOR COMPLETE DESIGNATION PREFIX WITH CIRCUIT NUMBER. (R1 IN CIRCUIT 200 IS R201).  
 11. (RESERVED)  
 10. (RESERVED)  
 9. PNP TRANSISTORS ARE 2N4037.  
 8. NPN TRANSISTORS ARE 2N4123.  
 7. CAPACITOR VALUES ARE IN MICROFARADS, 20%, 20V.  
 6. RESISTOR VALUES ARE IN OHMS, 5%, 1/4W.  
 (5) FOR SPARE LOGIC ELEMENTS, SEE TABLE V.  
 (4) FOR I.C. GENERIC TYPE NO. AND GROUND/VOLTAGE PIN NOS. SEE TABLE IV.  
 (3) (RESERVED)  
 (2) FOR VALUE, PART NUMBER AND USAGE OF COMPONENTS AFFECTED BY VERSION NUMBER, SEE TABLE II.  
 (1) FOR PART NUMBER OF COMPONENTS NOT AFFECTED BY VERSION NUMBER, SEE TABLE I.  
 NOTES: UNLESS OTHERWISE SPECIFIED

ASSEMBLY NUMBER 104811  
 SPECIFICATION NUMBER 104814  
 REFERENCE DRAWINGS

THIS DRAWING IS UNDER CONFIGURATION CONTROL.

SIGNATURES		DATE	PERTEC PERIPHERAL EQUIPMENT DIVISION
DATE		TITLE	
SCHEMATIC, WRITE		SIZE	DATE
104811		104810	104810





REVISIONS				
REV	DESCRIPTION	DATE	DR	CHK
A	ERN8-YD PRE-PROD RELEASE	8/1/74	W	W
A1	ECN 9731	8/1/74	W	W
B	ECN 9731	8/1/74	W	W
B	ECN 1010A	8/1/74	W	W
C	ECN 10215	8/1/74	W	W
D	ECN 10402	8/1/74	W	W
E	ECN 10479	8/1/74	W	W
F	ECN 10864	8/1/74	W	W
F1	ECN 11473	8/1/74	W	W
F2	ECN C12190	8/1/74	W	W
G	ECN C15092	8/1/74	W	W
H	ECN C17149	8/1/74	W	W
J	ECN C17570	8/1/74	W	W
K	ECN 78411	8/1/74	W	W

SCHEMATIC: 104810  
SPECIFICATION: 104814  
REF DWGS

PART NO 104811-03 REV S

QTY	PART NO.	DESCRIPTION	MATERIAL	FIN	REF. DES.	ITEM NO.
1	104811-03	PERTEC PERIPHERAL EQUIPMENT				
PCBA, WRITE						
SEE L/M						
104811						
2/1						

4. (DELETED)
3. MARK VERSION NO. AND VERSION ISSUE LETTER IN AREA SHOWN.
2. THIS ASSEMBLY SHALL BE MADE FROM PROCESS BOARD 104812-01 REV F AND SUBSEQUENT.
1. ASSEMBLE PER STANDARD MANUFACTURING METHODS.


NOTES: UNLESS OTHERWISE SPECIFIED

BLANK









REVISIONS					
REV	DESCRIPTION	DATE	DR	CHK	APP
2	PROTOTYPE RELEASE	1/1/74			
A	ERN 8-25 PRE-PROD RELEASE	1/1/74			
B	ECN 9839	1/1/74			
C	ECN 10117	2/2/77	CJ		
D	ECN 10051	2/2/77	CJ		
E	ERN 9-PY PROD RELEASE	11/1/77	CJ		
F	ECN 10361	2/2/77	R28		
G	ECN 10468	2/2/77	R28		
H	ECN 10824	1/1/78	J.S.		
I	ECN 10875	1/1/78	J.S.		
H1	ECN C12190	2/2/78	MM		
J	ECN C13220	1/1/78			


- ④ BEFORE INSTALLATION INSTALL POLARIZING KEY P/N 503-0004 AT P21-I.
- ⑤ BEFORE INSTALLATION REMOVE PIN 27 ON J202, PIN 19 ON J203 AND PIN 22 ON J204.
- ④ MASK AREAS SHOWN DURING FLOW SOLDER OPERATION.
- ② MARK VERSION NO. AND VERSION ISSUE LETTER IN AREA SHOWN.
- ② THIS ASSEMBLY SHALL BE MADE FROM PROCESS BOARD 104947-01 REV D AND SUBSEQUENT.
1. ASSEMBLE PER STANDARD MANUFACTURING METHODS.

NOTES: UNLESS OTHERWISE SPECIFIED

WIRE LIST 104945  
REF DWG5: THIS DRAWING IS UNDER CONFIGURATION CONTROL.  
PART NO. 104946- REV

QTY	PART NO.	DESCRIPTION	MATERIAL	FIN.	REF. DES.	ITEM NO.
SIGNATURES						
DATE						
PERTEC PERIPHERAL EQUIPMENT						
TITLE						
PCBA INTERCONNECT D						
MATERIAL						
SEE L/M						
SIZE CODE IDENT NO. DWG NO. 104946						
SCALE 2/1 DO NOT SCALE DWG SHEET 1 OF 1						

T1000  
NEXT ASSY  
APPLICATION



REVISIONS				
REV	DESCRIPTION	DATE	DR	CHK
A	ERN 10-RS PRODUCTION RELEASE	8/18/78	HM	HM
AI	ECN C12190	9/11/78	HM	HM
B	ECN C13064	9/11/78	MP	MP
C	ECN C13219	9/11/78	MP	MP
D	ECN C15258	9/11/78	L.A.	L.A.
E	ECN C15214	9/11/78	L.S.	L.S.

TABLE I	
PART NO.	503-3431
107298-01	OMIT
107298-02	USE

- 7 JUMPER WIRE ROUTING IS NOT CRITICAL AND MAY BE DETERMINED BY MANUFACTURING. ALL JUMPER WIRES ARE P/N 691-6030.
- 6 SEE TABLE I FOR USAGE
- 5 BEFORE INSTALLATION REMOVE PIN 27 ON J202, PIN 19 ON J203, PIN 22 ON J204 AND PIN 50 ON J24.
- 4 MASK AREAS SHOWN DURING FLOW SOLDER OPERATION.
- 3 MARK VERSION NO. AND VERSION ISSUE LETTER IN AREA SHOWN.
- 2 THIS ASSEMBLY SHALL BE MADE FROM PROCESS BOARD 107299-01 REV A AND SUBSEQUENT.
- 1, ASSEMBLE PER STANDARD MANUFACTURING METHODS.



NOTES: UNLESS OTHERWISE SPECIFIED

WIRE LIST 107301  
REF DWGS: THIS DRAWING IS UNDER CONFIGURATION CONTROL.  
PART NO. 107298 01 REVE

QTY. REQD	PART NO.	DESCRIPTION	MATERIAL	FIN.	REF. DES.	ITEM NO.
SIGNATURES						
DATE						
PERTEC PERIPHERAL EQUIPMENT						
TITLE						
PCBA INTERCONNECT DI						
MATERIAL						
SEE L/M						
SIZE						
E						
CODE IDENT. NO.						
107298						
REV						
E						
SCALE						
2/1						
DO NOT SCALE DWG						
SHEET						
1						

T1000
NEXT ASSY
APPLICATION

REVISIONS						
REV	DESCRIPTION	DATE	DR	CHK	APPR	
A	ERN 9-BR PRE PROD. RELEASE	11/14/76	TEW	PLJ	EP	
B	ECN 9794	3/14/77	EMP	K.T.	EP	
C	ECN 9857	4/21/77	RJ	K.T.	EP	
D	ERN 9-PH PROD RELEASE	7/2/77	SW	K.T.	EP	
E	ECN 10618	7/20/77	SW	K.T.	EP	
F	ECN 10674	11/1/77	J.S.	K.T.	EP	
G	ECN 10786	11/10/77	SW	K.T.	EP	
H	ECN 10824	12/14/77	J.S.	K.T.	EP	
I	ECN 10889	12/22/77	J.S.	K.T.	EP	
J	ECN 10945A	1/25/78	J.S.	K.T.	EP	
J1	ECN C12190	9/10/78	HM	K.T.	EP	



SCHEMATIC: 107189  
REF DWGS:

- ⑥ BEFORE INSTALLATION REMOVE PIN 1 ON J21.
- ⑤ INSTALL SCREW 608-1610 INTO BUSHING 613-0016 HOLDING BUSHING UNTIL TIGHT OR FLUSH WITH BOTTOM OF BOARD (4 PLCS).
- ④ THIS ASSEMBLY SHALL BE MADE FROM PROCESS BOARD 107101-01 REV A AND SUBSEQUENT.
- ③ MARK VERSION NO. AND VERSION ISSUE LETTER IN AREA SHOWN.
- ② THIS ASSEMBLY SHALL BE MADE FROM PROCESS BOARD 104952-01 REV A AND SUBSEQUENT.
- \*1 ASSEMBLE PER STANDARD MANUFACTURING METHODS.


NOTES: UNLESS OTHERWISE SPECIFIED

PART NO. 104951- REV

THIS DRAWING IS UNDER CONFIGURATION CONTROL.

SIGNATURES		DATE	<b>PERTEC</b> PERIPHERAL EQUIPMENT TITLE PCBA INTERCO CT F
DR. <i>TEW</i>		11/14/76	
CHK. <i>R. NOBLE</i>		11/14/76	
DES. <i>S. ROSSON</i>		11/14/76	
ENGR. <i>S. ROSSON</i>		11/14/76	SCALE 2 1 DO NOT SCALE DWG SHEET 1 OF 2
PROJ. ENGR.			
MATERIAL: SEE L/M		SIZE D	CODE IDENT NO. DWG NO. 104951 REV J1

107000	T1000
NEXT ASSY	1ST USED ON
APPLICATION	



W3

J21-21

J21-37

CR8

691-6030  
7 PLCS

A1 (REF)

A5 (REF)

600-0410  
604-2400  
615-0112

600-0412  
604-2400  
615-0112 } 2 PLACES

WIRING TABLE		
MNEMONIC	FROM	TO
OV (R)	A5-1	A1 TBI-9
SPOS	A5-2	A1 TBI-7
TPOS	A5-3	A1 TBI-8
-15V	A5-4	A1 TB4-7
+15V	A5-5	A1 TBI-6
TPOS I	A5-6	A1 J21-21
SPOS I	A5-7	A1 J21-37

104951 J1




TABLE I  
REFERENCE DESIGNATION

DESIGNATION	VALUE
100-0005	W2
100-1025	R5,14
100-1025	R3,9
100-2245	R7
100-4725	R4,8
101-1015	H12
101-4705	R11
101-5605	R10
107-1000	R106,206
107-1001	R102,202
124-1030	R13
124-1040	R15
124-5040	R6
107-1003	R104,105,204,205
107-5112	R101,201
121-1020	R103,203
100-4745	R1
130-1005	C1
135-1002	C5,6
135-4742	C4
139-2244	C2,3
200-4123	Q1
300-1002	CR6,7,8
300-4446	CR1,2,3,4,5,101,102,201,202
400-0307	U101,201
400-0311	U1,4
400-0318	U3
691-0030	W3
710-7413	U2

REFERENCE DESIGNATION

LAST USED	NOT USED	DELETED
C6		
CR8		
J22		
Q1		
R15		
TB4		
TP5		
U4		
W3		
S15		


TABLE II

ASSEMBLY	VERSION	W1	R107,208	R108	R207
107000	107000	100-0005	100-1000	34.8	107-0348
107000	107000	100-0005	100-1000	34.8	107-0348

1. WIRE IS 24 GA WHITE.  
2. DIODES ARE IN 4446.  
3. (RESERVED)  
4. (RESERVED)  
5. (RESERVED)  
6. CAPACITORS ARE IN MICROFARADS, 120%.  
7. RESISTOR VALUES ARE IN OHMS, 1/4W, 5%.  
8. (RESERVED)  
9. (RESERVED)  
10. (RESERVED)  
11. (RESERVED)  
12. (RESERVED)  
13. (RESERVED)  
14. (RESERVED)  
15. (RESERVED)  
16. (RESERVED)  
17. (RESERVED)  
18. (RESERVED)  
19. (RESERVED)  
20. (RESERVED)  
21. (RESERVED)  
22. (RESERVED)  
23. (RESERVED)  
24. (RESERVED)  
25. (RESERVED)  
26. (RESERVED)  
27. (RESERVED)  
28. (RESERVED)  
29. (RESERVED)  
30. (RESERVED)  
31. (RESERVED)  
32. (RESERVED)  
33. (RESERVED)  
34. (RESERVED)  
35. (RESERVED)  
36. (RESERVED)  
37. (RESERVED)  
38. (RESERVED)  
39. (RESERVED)  
40. (RESERVED)  
41. (RESERVED)  
42. (RESERVED)  
43. (RESERVED)  
44. (RESERVED)  
45. (RESERVED)  
46. (RESERVED)  
47. (RESERVED)  
48. (RESERVED)  
49. (RESERVED)  
50. (RESERVED)  
51. (RESERVED)  
52. (RESERVED)  
53. (RESERVED)  
54. (RESERVED)  
55. (RESERVED)  
56. (RESERVED)  
57. (RESERVED)  
58. (RESERVED)  
59. (RESERVED)  
60. (RESERVED)  
61. (RESERVED)  
62. (RESERVED)  
63. (RESERVED)  
64. (RESERVED)  
65. (RESERVED)  
66. (RESERVED)  
67. (RESERVED)  
68. (RESERVED)  
69. (RESERVED)  
70. (RESERVED)  
71. (RESERVED)  
72. (RESERVED)  
73. (RESERVED)  
74. (RESERVED)  
75. (RESERVED)  
76. (RESERVED)  
77. (RESERVED)  
78. (RESERVED)  
79. (RESERVED)  
80. (RESERVED)  
81. (RESERVED)  
82. (RESERVED)  
83. (RESERVED)  
84. (RESERVED)  
85. (RESERVED)  
86. (RESERVED)  
87. (RESERVED)  
88. (RESERVED)  
89. (RESERVED)  
90. (RESERVED)  
91. (RESERVED)  
92. (RESERVED)  
93. (RESERVED)  
94. (RESERVED)  
95. (RESERVED)  
96. (RESERVED)  
97. (RESERVED)  
98. (RESERVED)  
99. (RESERVED)  
100. (RESERVED)

ASSEMBLY NO. 107000  
WIRE LIST NO. 107007

PERTEC  
PERIPHERAL EQUIPMENT DIVISION  
SCHEMATIC  
BASE ASSY  
107189  
JUL 1967



NOTES: UNLESS OTHERWISE SPECIFIED

WIRE LIST NO.104959

THIS DRAWING IS UNDER CONFIGURATION CONTROL.


NOTES: UNLESS OTHERWISE SPECIFIED

NOMINAL INPUT	FROM S2-1 TO <b>(6)</b>	FROM B1-1 & C1-2 TO
190 VAC	AI TBI-3	AI TBI-6
200 VAC	AI TBI-4	AI TBI-7
210 VAC	AI TBI-3	AI TBI-7
220 VAC	AI TBI-4	AI TBI-8
230 VAC	AI TBI-3	AI TBI-8
240 VAC	AI TBI-4	AI TBI-9
250 VAC	AI TBI-3	AI TBI-9


REFERENCE DESIGNATIONS		
LAST USED	NOT USED	DELETED
B2		
C5		
CB1		
CR3		
E2		E3,4
ETM1		
F7		
JI		
		MI
R4		
S3		
TI		
A) TB1		

	T1000	APPROX
NEXT ASSY	1ST USED ON	FINISH
APPLICATION		




















































REVISIONS				
REV	DESCRIPTION	DATE	DR	CHK APPR
A	ERN12-KF PROD. REL.	1/1/80	CADD	
X B	ECN C15020	1/1/80	AS	
X C	ECN C15300	1/1/80	AS	
X D	ECN C15511	1/1/80	AS	
X E	ECN C15675A	1/1/80	AS	
X F	ECN C15831B	1/1/80	AS	
X G	ECN C15978A	1/1/80	AS	
X H	ECN C17034B	1/1/80	AS	
X I	ECN C17143C	1/1/80	AS	
X J	ECN C17159	1/1/80	AS	
X K	ECN C173978A	1/1/80	AS	
X L	ECN C17434A	1/1/80	AS	
X M	ECN C17605	1/1/80	AS	
X N	ECN C17778	1/1/80	AS	
X P	ECN C18411	1/1/80	AS	

3 MARK VERSION NO. AND VERSION ISSUE LETTER IN AREA SHOWN.

2 THIS ASSEMBLY SHALL BE MADE FROM PROCESS BOARD 106877-01 REVC AND SUBSEQUENT.

1. ASSEMBLE PER STANDARD MANUFACTURING METHODS.

NOTES: UNLESS OTHERWISE SPECIFIED

SCHEMATIC: 106875

REFERENCE DRAWINGS:

PART NO. 10687602REVS  
18837418783

UNDER CONFIGURATION CONTROL

TOP ASSY	T 1000	FINISH:	MATL:	SIZE	CODE	IDENT NO	OWN NO.	REV
NEXT ASSY	INT USED ON	SEE LM		E 32097			106876	P
APPLICATION				SCALE	2:1	DO NOT SCALE DIM	SHEET 1	

SIGNATURES	DATE	PERTEC
DR CADD	2/90	A DIVISION OF PERTEC COMPUTER CORPORATION
DES		TITLE
ENGR		PCBA, CONTROL M2
PROJ ENGR		

BLANK




TABLE I ①

Table with 2 columns: PART NO. and REFERENCE DESIGNATION. It lists various components and their associated part numbers, such as R117, R120, R150, etc.

TABLE I ①

Table with 2 columns: PART NO. and REFERENCE DESIGNATION. It lists various components and their associated part numbers, such as Q18, R5, R6, etc.

TABLE V ⑤




Table with 3 columns: LAST USED, NOT USED, and DELETED. It lists various components and their status, such as C52, CR26, J20, etc.


TABLE IV ④


Table with 5 columns: I.C. TYPE, +15V, +5V, GND, and -15V. It lists various components and their associated part numbers, such as 74SL00, 74SL10, etc.


- ⑦ TPI THRU 3,5,7,9,11,13,15,17,19,20
25 THRU 48,54,63 ARE NOT USED.
16 (RESERVED)
15 (RESERVED)
14 (RESERVED)
③ COMPONENTS REQUIRE HEATSINK.
12. RESISTORS WITH 1% TOLERANCE ARE 1/8W.
11. SIGNALS ARE CROSS-REFERENCED BETWEEN SHEETS AND WITHIN A SHEET BY NUMBERS APPEARING UNDER THE ASSOCIATED LOGIC TERM MNEMONIC. THE FIRST NO. IS THE SHEET NO. AND THE SECOND NO. IS THE ZONE NO.
10. DIODES ARE IN 4446.
9. PNP TRANSISTORS ARE 2N2905
8. NPN TRANSISTORS ARE 2N2905.
7. CAPACITOR VALUES ARE IN MICROFARADS
6. RESISTOR VALUES ARE IN OHMS 5%, 1/4.
⑤ FOR SPARE LOGIC ELEMENTS SEE TABLE V.
④ FOR I.C. GENERIC TYPE NUMBER AND GROUND/VOLTAGE PIN NUMBERS SEE TABLE IV.
3 (RESERVED)
2 (RESERVED)
① FOR PART NUMBER OF COMPONENTS NOT AFFECTED BY VERSION NUMBER, SEE TABLE I.
NOTES: UNLESS OTHERWISE SPECIFIED
SPECIFICATION 106925
ASSEMBLY 106926
REFERENCE DRAWINGS


THIS DRAWING IS UNDER CONFIGURATION CONTROL

Form containing various fields for configuration control, including revision history, signatures, dates, and part numbers. It includes a title block with the title 'SCHEMATIC, REEL SERVO' and a part number '106925'.











BLANK














REVISIONS				
REV	DESCRIPTION	DATE	DR	CHK
1	A. ERM 9-80 PROD REL.			
2	B. ERM 10344A, C. ERM 104031			
3	L. ERM 10393, E. ERM 10354			
4	F. ERM 10440, G. ERM 10679			
5	H. ERM 10674A, J. ERM 10757			
6	K. ERM 10795, L. ERM 10789			
7	M. ERM 10910A, N. ERM 11057			
8	ECN 11187	11/18/77	ECN	ECN
9	ECN 11181 SHFT REDRAWN	11/18/77	ECN	ECN
10	ECN 11189	11/18/77	ECN	ECN
11	ECN 11257	11/18/77	ECN	ECN
12	ECN 11252	11/18/77	ECN	ECN
13	ECN 11252	11/18/77	ECN	ECN
14	ECN 11252	11/18/77	ECN	ECN
15	ECN 11252	11/18/77	ECN	ECN
16	ECN 11252	11/18/77	ECN	ECN
17	ECN 11252	11/18/77	ECN	ECN
18	ECN 11252	11/18/77	ECN	ECN
19	ECN 11252	11/18/77	ECN	ECN
20	ECN 11252	11/18/77	ECN	ECN
21	ECN 11252	11/18/77	ECN	ECN
22	ECN 11252	11/18/77	ECN	ECN
23	ECN 11252	11/18/77	ECN	ECN
24	ECN 11252	11/18/77	ECN	ECN
25	ECN 11252	11/18/77	ECN	ECN
26	ECN 11252	11/18/77	ECN	ECN
27	ECN 11252	11/18/77	ECN	ECN
28	ECN 11252	11/18/77	ECN	ECN
29	ECN 11252	11/18/77	ECN	ECN
30	ECN 11252	11/18/77	ECN	ECN
31	ECN 11252	11/18/77	ECN	ECN
32	ECN 11252	11/18/77	ECN	ECN
33	ECN 11252	11/18/77	ECN	ECN
34	ECN 11252	11/18/77	ECN	ECN
35	ECN 11252	11/18/77	ECN	ECN
36	ECN 11252	11/18/77	ECN	ECN
37	ECN 11252	11/18/77	ECN	ECN
38	ECN 11252	11/18/77	ECN	ECN
39	ECN 11252	11/18/77	ECN	ECN
40	ECN 11252	11/18/77	ECN	ECN
41	ECN 11252	11/18/77	ECN	ECN
42	ECN 11252	11/18/77	ECN	ECN
43	ECN 11252	11/18/77	ECN	ECN
44	ECN 11252	11/18/77	ECN	ECN
45	ECN 11252	11/18/77	ECN	ECN
46	ECN 11252	11/18/77	ECN	ECN
47	ECN 11252	11/18/77	ECN	ECN
48	ECN 11252	11/18/77	ECN	ECN
49	ECN 11252	11/18/77	ECN	ECN
50	ECN 11252	11/18/77	ECN	ECN
51	ECN 11252	11/18/77	ECN	ECN
52	ECN 11252	11/18/77	ECN	ECN
53	ECN 11252	11/18/77	ECN	ECN
54	ECN 11252	11/18/77	ECN	ECN
55	ECN 11252	11/18/77	ECN	ECN
56	ECN 11252	11/18/77	ECN	ECN
57	ECN 11252	11/18/77	ECN	ECN
58	ECN 11252	11/18/77	ECN	ECN
59	ECN 11252	11/18/77	ECN	ECN
60	ECN 11252	11/18/77	ECN	ECN
61	ECN 11252	11/18/77	ECN	ECN
62	ECN 11252	11/18/77	ECN	ECN
63	ECN 11252	11/18/77	ECN	ECN
64	ECN 11252	11/18/77	ECN	ECN
65	ECN 11252	11/18/77	ECN	ECN
66	ECN 11252	11/18/77	ECN	ECN
67	ECN 11252	11/18/77	ECN	ECN
68	ECN 11252	11/18/77	ECN	ECN
69	ECN 11252	11/18/77	ECN	ECN
70	ECN 11252	11/18/77	ECN	ECN
71	ECN 11252	11/18/77	ECN	ECN
72	ECN 11252	11/18/77	ECN	ECN
73	ECN 11252	11/18/77	ECN	ECN
74	ECN 11252	11/18/77	ECN	ECN
75	ECN 11252	11/18/77	ECN	ECN
76	ECN 11252	11/18/77	ECN	ECN
77	ECN 11252	11/18/77	ECN	ECN
78	ECN 11252	11/18/77	ECN	ECN
79	ECN 11252	11/18/77	ECN	ECN
80	ECN 11252	11/18/77	ECN	ECN
81	ECN 11252	11/18/77	ECN	ECN
82	ECN 11252	11/18/77	ECN	ECN
83	ECN 11252	11/18/77	ECN	ECN
84	ECN 11252	11/18/77	ECN	ECN
85	ECN 11252	11/18/77	ECN	ECN
86	ECN 11252	11/18/77	ECN	ECN
87	ECN 11252	11/18/77	ECN	ECN
88	ECN 11252	11/18/77	ECN	ECN
89	ECN 11252	11/18/77	ECN	ECN
90	ECN 11252	11/18/77	ECN	ECN
91	ECN 11252	11/18/77	ECN	ECN
92	ECN 11252	11/18/77	ECN	ECN
93	ECN 11252	11/18/77	ECN	ECN
94	ECN 11252	11/18/77	ECN	ECN
95	ECN 11252	11/18/77	ECN	ECN
96	ECN 11252	11/18/77	ECN	ECN
97	ECN 11252	11/18/77	ECN	ECN
98	ECN 11252	11/18/77	ECN	ECN
99	ECN 11252	11/18/77	ECN	ECN
100	ECN 11252	11/18/77	ECN	ECN

REFERENCE DRAWINGS  
SCHEMATIC NO. 107307  
WIRE LIST NO. 107007  
INTERCONNECT DIAGRAM 107002

Part No. 107000-01 (Rev. CK)  
+ ECN 18705, 18749, 18752, 19094

THIS DRAWING IS UNDER CONFIGURATION CONTROL.

SIGNATURES	DATE	PERTEC PERIPHERAL EQUIPMENT
DR. E. STARZEC	11/17/77	TITLE
CHK. J. J. J.	11/17/77	BASE ASSY
APP. J. J. J.	11/17/77	SIZE
APP. J. J. J.	11/17/77	SCALE
APP. J. J. J.	11/17/77	DO NOT SCALE DWG
APP. J. J. J.	11/17/77	MAN. RES.


TOP BILL T1000 FINISH

APPLICATION SEE L/M

SCALE NONE

DO NOT SCALE DWG

MAN. RES.




REVISIONS					
REV	DESCRIPTION	DATE	DR	CHK	APPR
A	ERN 10-DV PROD. RELEASE	11/17/77	WJ	WJ	WJ
A1	ECN C12190	11/17/77	WJ	WJ	WJ
B	ECN C12647	11/17/77	L.R.	WJ	WJ

TABLE I

PART NO.	REF. DESIGNATION
301-0002	CR1, CR2, CR3, CR4, CR5, CR6, CR7
514-0011	S2, S3, S4, S5
506-6303	S1
691-0022	W1

TABLE II

REF DESIGNATION	
LAST USED	DELETED
CR7	
S5	
W1	



2 FOR ASSY DWG SEE 107257.

1 FOR PART NUMBER OF COMPONENTS NOT AFFECTED BY VERSION NUMBER SEE TABLE I.


NOTES: UNLESS OTHERWISE SPECIFIED.

THIS DRAWING IS UNDER CONFIGURATION CONTROL.

SIGNATURES		DATE	<b>PERTEC</b> a division of Perdec Computer Corporation <b>SCHEMATIC</b> <b>CONTROLS ASSY (TU77)</b>
DR. <i>[Signature]</i>		11/17/77	
CHK. <i>[Signature]</i>		11/17/77	
DES. <i>[Signature]</i>		11/17/77	
ENGR. <i>[Signature]</i>			
PROJ. ENGR.			
FINISH:		MATL:	SIZE <b>D</b> CODE IDENT NO. <b>32097</b> DWG NO. <b>107266</b> REV <b>B</b> SCALE <b>NONE</b> DO NOT SCALE DWG SHEET <b>1</b> OF <b>1</b>

NOTES: UNLESS OTHERWISE SPECIFIED

DETAILS: POST CLEARPRINT 300



REVISIONS					
REV	DESCRIPTION	DATE	DR	CHK	APPR
A	ERU 10-DV PROD RELEASE	8-11-77	AM	AM	AM
A1	ECN C12190	7/9/78	HM	HM	HM
A2	ECN C12167	4/24/78	HM	RAS	HM
B	ECN C12661	2-11-78	R3B	AM	AM
C	ECN C12647	3/4/79	L.R	RUB	AM

VERSION TABLE 6			
VERSION NO.	MODEL	DISPLAY OVERLAY	DENSITY
-01	TU 77	107256-01	800/1600
-02	TU 78	107256-02	6250/1600

FOR SCHEMATIC SEE 107266

THIS DRAWING IS UNDER CONFIGURATION CONTROL.

SIGNATURES		DATE	<b>PERTEC</b> a division of Perdec Computer Corporation	
CHK	<i>[Signature]</i>	8-11-77		
CHK	<i>[Signature]</i>	10-27-77	TITLE <b>CONTROLS ASSY, TU 77</b>	
DES	<i>[Signature]</i>	11/1/77		
ENGR	<i>[Signature]</i>	11-2-77		
PROJ. ENGR	<i>[Signature]</i>	11/1/77	SIZE CODE IDENT NO. DWG NO. REV <b>D 32097 107257 C</b>	
FINISH:				
MATERIAL: SEE L/M			SCALE NONE DO NOT SCALE DWG SHEET 1 OF 1 MAN. REQ.	

- 6 SEE VERSION TABLE FOR CORRECT DISPLAY OVERLAY.
5. BEFORE INSTALLATION OF COMPONENTS, REMOVE ALL BURRS AND METAL CHIPS FROM MOUNTING SURFACE.
4. ASSEMBLE PER STANDARD MANUFACTURING METHODS.
- 3.
- 2 THIS ASSY SHALL BE MADE FROM PROCESS BOARD 104957-01 REV. B & SUBSEQUENT.
- 1 MARK PART NO. 107257, APPROPRIATE VERSION NO. AND APPLICABLE REV. LETTER, LOCATE APPROX. AS SHOWN.
- NOTES: UNLESS OTHERWISE SPECIFIED

TOP ASSY	T 1000
NEXT ASSY	1ST USED ON
APPLICATION	




REVISIONS					
REV	DESCRIPTION	DATE	DR	CHK	APP
A	ERN 12-MY PROD. RELEASE	2-12-80	SRC	AM	EM

① TABLE I

PART NO.	REF. DESIGNATION
301-0002	CR1, CR2, CR3, CR4, CR5 CR6, CR7
514-0011	S2, S3, S4, S5
506-6303	S1
691-0022	W1

TABLE II

REF DESIGNATION		
LAST USED	NO USED	DELETED
CR7		
S9 ③	S6, 7, 8	
W1		



③ DOOR SAFETY SWITCH-SEE TOP ASSY FOR USAGE.

2. FOR ASSY DWG SEE 109536.

① FOR PART NUMBERS OF COMPONENTS NOT AFFECTED BY VERSION NUMBER SEE TABLE I.

NOTES: UNLESS OTHERWISE SPECIFIED.

THIS DRAWING IS UNDER CONFIGURATION CONTROL.

The information herein is the property of PERTEC CORPORATION. No portion of this data shall be released, disclosed, used, or duplicated, for procurement or manufacturing purposes without specific written consent of PERTEC.		SIGNATURES		DATE
UNLESS OTHERWISE SPECIFIED		DR. SYD CROWELL		2-12-80
DIMENSIONS ARE IN INCHES		CHK		
TOLERANCES:		DES		
.XX ±		ENGR		
.XXX ±		PROJ ENGR		
BREAK ALL SHARP CORNERS APPROX. .010		MATL		
FINISH:		SCALE		
NEXT ASSY		CODE IDENT NO.		
APPLICATION		DWG NO.		
		109535		
		REV		
		A		

109536 1/1000  
NEXT ASSY  
APPLICATION

**PERTEC**  
a division of Peritek Computer Corporation  
TITLE  
SCHEMATIC,  
CONTROLS ASSEMBLY  
(TU77/78)  
SIZE D 32097  
SCALE NONE  
DO NOT SCALE DWG  
SHEET 1



BLANK



**PERTEC**  
**COMPUTER CORPORATION**  
Peripherals Division  
P.O. Box 2198  
Chatsworth, CA 91311  
(213) 882-0030  
TWX (910) 494-2093